



BioClean-C™ Sleeve Covers BCSC

Non-sterile cleanroom sleeve covers, for protection against chemotherapy drugs

- **Optimized protection:** BioClean™ chemotherapy-protective sleeve covers are specially developed to protect against a range of chemotherapy drugs, with ultrasonically bonded seams and protective tape, for added security
- **Guaranteed cleanliness:** These chemotherapy-protective garments are constructed from CleanTough™ material that is both lightweight and low-linting
- **Assured barrier protection:** BioClean-C™ chemotherapy-protective sleeve covers have been tested against ASTM F739-12 permeation standards
- **Maximized practicality:** These one-size-fits-all sterile sleeve covers are tailored for quick and simple donning
- **Ultrasonically bonded seam:** For sleeve covers that offer a secure fit
- **Lightweight, low-linting CleanTough™ fabric:** Comfort and durability
- **ASTM F739-12 compliance:** Assured permeation protection



Industries

- Controlled and Critical Environments
- Production and Manufacturing
- Laboratory and Research





BioClean-C™ Sleeve Covers BCSC

TECHNICAL DATA SHEET

PRODUCT INFORMATION

Material	CleanTough™
Audit Standards	Manufacturing QMS Audit Standards ISO 9001, PPE Regulation 2016 425 Module D
Standards	ASTM F739, CE 0598, EN 13935-2, EN ISO 14325, EN ISO 13688:2013, Category III, EN 13034:2005 + A1:2009
Country Of Origin	China
Cleanroom Class	Class 10/ISO 4
Shelf Life	Five (5) years from date of manufacture.
Construction	Ultrasonically bonded seams covered with protective tape
Characteristics	Low particulating

MATERIAL PERFORMANCE TEST RESULTS

TEST	RESULT	PERFORMANCE CLASS
Abrasion Resistance	10 to 100 cycles	1
Trapezoidal Tear Resistance Cross Direction (CD)	CD 32.3 N	2
Trapezoidal Tear Resistance Machine Direction (MD)	MD 50.6 N	3
Tensile Strength Cross Direction (CD)	CD 47 N	1
Tensile Strength Machine Direction (MD)	MD 94 N	2
Puncture Resistance	10 N	1
Repellence to Liquids - 30% H ₂ SO ₄	99.0%	3
Repellence to Liquids - 10% NaOH	98.4%	3
Repellence to Liquids - O-Xylene	91.4%	1
Repellence to Liquids - Butan-1-ol	93.9%	3
Penetration by Liquids - 30% H ₂ SO ₄	0%	3
Penetration by Liquids - 10% NaOH	0%	3
Penetration by Liquids - O-Xylene	0%	3
Penetration by Liquids - Butan-1-ol	0%	3
Seam Strength ¹	74 N	2

1. Seam not destroyed



BioClean-C™ Sleeve Covers BCSC

PARTICLE SHEDDING TEST RESULTS

TEST	RESULT
Particle Shedding (Helmke Drum Test)	≥ 0.5Qm (counts/min) <1700

ASTM F739-12 TEST METHOD RESULTS

DRUG	Mean Breakthrough Time (MBT), Minutes Breakthrough of the test chemical is deemed to have occurred when the permeation rate has reached 0.1 Qg/cm ² /min
CISPLATIN	>240
CARMUSTINE	>240
CYCLOPHOSAMIDE	>240
DOXORUBICINHYDROCHLORIDE	>240
5-FLUOROURACIL	>240
METHOTREXATE	>240
ETOPOSIDE	<6
PACLITAXEL	>240
THIOTEPA	55 (46,88,31)

Results achieved under controlled laboratory conditions, by accredited external testing laboratory.

SIZE CHART

BCSC; Size: Universal

ORDERING INFORMATION

BCSC	SIZE	BioClean-C Chemo Sleeve Covers BCSC
BCSC	REORDER NO.	BCSC

For additional information visit us at www.ansell.com, or call us at

Europe, Middle East & Africa Region

Ansell Healthcare Europe NV
T: +32 (0) 2 528 74 00
F: +32 (0) 2 528 74 01

Asia Pacific Region

Ansell Global Trading Center
T: +603 8310 6688
F: +603 8310 6699

North America Region

Ansell Healthcare Products LLC
US T: +1 800 800 0444
US F: +1 800 800 0445
CA T: +1-800-363-8340

Latin America & Caribbean Region

Ansell Commercial Mexico S.A. de C.V.
T: +52 442 248 1544 / 248 3133

Australia

Ansell Limited
T: +61 1800 337 041
F: +61 1800 803 578

UK

Ansell Nitritex
T: +44 1638 663338
F: +44 1638 668890

Performance Standards and Regulatory Compliance

CE 0598



Ansell, ® and ™ are trademarks owned by Ansell Limited or one of its affiliates. US Patented and US and non-US Patents Pending: www.ansell.com/patentmarking © 2022 Ansell Limited. All Rights Reserved.

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Please see product validation pack or contact Ansell customer service for specific data on use of garments with cytotoxic drugs. Garments used for protection against such drugs must be selected specifically for the type of chemicals used.

